




TECH TIPS

TURNING THE SCREEN OFF ON A CANVIEW 4 SWITCH PANEL

NO. 141



SERVICE CALL:
TURNING THE SCREEN OFF ON A
CANVIEW 4 SWITCH PANEL



MODEL(S):
ALL TEREX UTILITIES EQUIPMENT
USING THE CANVIEW 4 SWITCH
PANEL



TOOLS NEEDED:
NONE

TEREX UTILITIES TECHNICAL SUPPORT TEAM

PHONE: 1-844-TEREX4U (1-844-837-3948) | EMAIL: UTILITIES.SERVICE@TEREX.COM



DANGER

Failure to obey the instructions and safety rules in the appropriate Operator's Manual and Service Manual for your machine will result in death or serious injury.

Many of the hazards identified in the Operator's Manual are also safety hazards when maintenance and repair procedures are performed.

DO NOT PERFORM MAINTENANCE UNLESS:

- ✓ You are trained and qualified to perform maintenance on this machine.
- ✓ You read, understand and obey:
 - manufacturer's instructions and safety rules
 - employer's safety rules and worksite regulations
 - applicable governmental regulations
- ✓ You have the appropriate tools, lifting equipment and a suitable workshop.

The information contained in this Tech Tip is a supplement to the Service Manual. Consult the appropriate Service Manual of your machine for safety rules and hazards.



TECH TIP 141 | RELEASED 12.11.2023 | VERSION 1.0
©TEREX UTILITIES. ALL RIGHTS RESERVED

STEP 1

Locate the switch panel inside the cab.



STEP 2

Press and hold the home/select button for 5 seconds until the screen turns black.



STEP 3

To awaken the screen press any of the black buttons.



FOR FURTHER ASSISTANCE,
CONTACT THE TEREX UTILITIES TECHNICAL SUPPORT TEAM
PHONE: **1-844-TEREX4U (1-844-837-3948)** | EMAIL: **UTILITIES.SERVICE@TEREX.COM**
